

Instruction

LANGIR[™]



- I, Take out the head with a starter, and unscrew the aluminum screw.
- II ,Then put the switch into the panel's hole.
- ${1}\hspace{-0.1cm}{\rm l}$,Screw the screw, then put the head onto the switch.

Installation Dimensions



Туре	А	В	С
Normal,Key-lock	≥50mm	≥40mm	Φ22mm Φ25mm
Selector	≥55mm	≥40mm	
Mushroom	≥50mm	≥50mm	Ф30mm
Big Mushroom	≥70 mm	≥70mm	

Circuit Diagram





The switch code is 11.
1,2 are normal closed;
3,4 are normal opened;
The NC contact and NO contact can be combined freely

The Contact Pair's Close-open State Chart of the Selector Switches and Key-lock Switches.

a ,The Contact Pair's Close-open State Chart of 2-position Selector Switch.

Number	Typde	•	•
1	Y090-11 ■ /2◆		
2	Y090-02 ■ /2◆	• • • •	0 0 0 0
3	Y090-20 ■ /2◆	0000	•1••1•
4	Y090-22 ■ /2◆		
5	Y090-13 ■ /2◆		
6	Y090-31 ■ /2◆	0 0 0 0	
7	Y090-04 ■ /2◆		0000
8	Y090-40 ■ /2◆	0000	
9	Y090-42 ■ /2◆		
10	Y090-24 ■ /2◆		
11	Y090-06 ■ /2◆		0 0 0 0
12	Y090-60 ■ /2◆	0000	
13	Y090-33 ■ /2◆		
14	Y090-15 ■ /2◆		
15	Y090-51 ■ /2◆		

Note:1, $\frac{1}{OO}$ express open state, $\bullet 1 \bullet$ express close state.

2, If you need other contact state, please tell us.

b, The Contact Pair's Close-open State Chart of 3-position Selector Switch.

Number	Туре	•	•	Ø
1	Y090 - 11 ■ /3◆	•1• •1•		0 0 0 0
2	Y090-02 ■ /3◆	0 0 11	•••••	•1• ○ ○
3	Y090 - 20 ■ /3◆		0 0 0 0	
4	Y090 - 22 ■ /3◆			
5	Y090 - 13 ■ /3◆			
6	Y090 - 31 ■ /3◆		0 0 0 0	0000
7	Y090-04■/3◆			
8	Y090 - 40 ■ /3◆		0000	
9	Y090 - 42 ■ /3◆			
10	Y090-24 ■ /3◆			
11	Y090-06 ■ /3◆			
12	Y090-60 ■ /3◆		0000	
13	Y090-33■/3◆			0000
14	Y090 - 15 ■ /3◆			
15	Y090-51 ■ /3◆		0000	